



# SERVICE TECHNICIANS INSTRUCTION |

**Distribution:**

GEJ-Service  
Subsidiaries-Service  
Service partners

ST-023 | **No.**

17.01.05 | **Date**

GE Jenbacher | **from**  
H. Sonnerer | Service  
tel 2168 - fax 42168

## Engine shutdown

Because of the great importance of safety for man and machine we wish to refer once more to the Technical Instruction 1100-0105, which describes the correct shut down of the engine. You will find it on page 2 of this instruction.

**The module must be shut down appropriately for all service and maintenance operations and for troubleshooting on module and control panels according to TI 1100-0105!**

Particularly important is the changeover of the Service selection switch to STOP! It is possible for instance with dia.ne XT – systems for the engine to start automatically after a reboot of the control if the following applies:

- Mode selector switch AUTOMATIC
- Demand switch ON
- No tripping alarm present (this is normally the case after a reboot)

As a protection for the system, but first of all for your own safety, individual's own methods have to be omitted and the described procedure adhered to in any case!

